


[Seamingly Accurate Seam Guide](#)

[Purchase Here](#)

Tired of having inaccurate seams? Is your sewing machine covered in masking tape for your wider hemming and sewing needs? Wish you had a REAL guide beyond the metal throat plate? Do you have a metric machine and need an “inches” guide for your new patterns?



Seamingly Accurate? is

a new product allowing you to sew hems, apply trims, quickly make half-square-triangles and more without permanently altering your sewing machine! This product has been designed by me, owner and founder of ReannaLily Designs. I found, in my commissioned sewing endeavors, that I really needed more sewing guide lines. It occurred to me, that you might also.

Seamingly Accurate? has been an editor’s pick for “Best Half Square Triangle” method in a few different magazines. And the guide was even offered as a sweepstakes prize for Vogue Pattern Magazine. Click the magazines to read more about the article.



How To Install the Seamingly Accurate? Seam Guide


1. Peel off the backing of **Seamingly Accurate?** to expose the repositionable adhesive.

2. Apply **Seamingly Accurate?** to your sewing machine over and around the throat plate, lining up the black “needle line” of **Seamingly Accurate?** with your needle as shown.

Use any straight lines on your machine such as the edge of the throat plate to help you line up your **Seamingly Accurate?** straight on your machine. Use a ruler to help you. Remember that you can remove and reposition it many times if needed. If you have an accessory case that opens or a removable table, or free-arm bed, make a cut in the **Seamingly Accurate?** so you can open your accessory case or remove your arm or table without removing **Seamingly Accurate?**. You can position **Seamingly Accurate?** any way you like.

3. Using a craft knife, cut around your metal throat plate and bob-bin case. Remove this piece of paper, or you can mark where you want to cut with a pencil, remove **Seamingly Accurate?** from your machine, cut with scissors, and reposition **Seamingly Accurate?** on the machine. If you have an accessory case that opens or a removable table, or free-arm bed, make a cut in the **Seamingly Accurate?** so you can open your accessory case or remove your arm or table without removing **Seamingly Accurate?**.

4. Now your guide is fitted to your sewing machine and can be easily used on many occasions.



Your throat plate position will vary depending on your sewing machine brand. ReannaLily Designs recommends removing that portion, in case you need access to that pesky bobbin case during your sewing afternoon.

